AUDIBLE ALARM



AUDIBLE ALARM

Little GIANT.





















INSTRUCTIONS

- Remove the Little Giant (513350)
 Water Alarm from the outer packaging. (FIG.A)
- 2. Cut off the remote sensor with wire cutters. (FIG.B)
- 3. Shut off electrical power at fuse box before making any connections.
- Strip back both wires and connect, to high level safety switch leads on the condensate

- pump via inline switch enclosed. (FIG.C)
- Undo retaining screw on motor cover and remove the motor cover from the condensate pump. (FIG.D)
- Change over the spade terminal on the safety switch from the middle terminal (NO - Normally Open) to the top terminal (NC -Normally Closed). (FIG.E), (FIG.F), (FIG.G)
- 7. Remove the back cover of the Water Alarm and fit a 9 Volt battery (Not Supplied). (FIG.H)
- 8. Test alarm by raising the high level float arm connected to safety switch.
- 9. Replace the motor cover and re-fit retaining screw.
- Replace the cover and mount using the single screw fixing point. (FIG.I)

PUMPS AUDIBLE ALARM

Little GIANT.



Glaisdale Drive East Nottingham NG8 4LY United Kingdom